



# TC8000




## Touch Computer



---

## Quick Start Guide

# Features




## Battery Installation



## Charge the TC8000

1. Insert the TC8000 into the cradle.




2. The TC8000 starts to charge automatically. The TC8000 charges in approximately four hours.

LED State	Description
Solid Amber	TC8000 is charging.
Solid Green	TC8000 is fully charged.
Fast Blinking Red	Charging error.
Off	Not charging.

## Scanning

To scan bar codes:

1. Open an application and ensure that a text field is in-focus.
2. Press the trigger and aim the exit window at a bar code.



# Get More Information

For more information on using the TC8000, refer to the **TC8000 User Guide**.

Go to <http://www.zebra.com/support> to view the *TC8000 User Guide* and *TC8000 Integrator Guide*.

Zebra reserves the right to make changes to any product to improve reliability, function, or design.

Zebra does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any patent right or patent, covering or relating to any combination, system, apparatus, machine, material, method, or process in which Zebra products might be used. An implied license exists only for equipment, circuits, and subsystems contained in Zebra products.



Zebra Technologies Corporation  
3 Overlook Point  
Lincolnshire, Illinois 60069 USA  
<http://www.zebra.com>

Zebra and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners.

© 2015 Symbol Technologies LLC, a subsidiary of Zebra Technologies Corporation.

